

Manual, Assembly instruction: Brodit 655768

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press down on the upper part of the Proclip so that the angled edge hooks firmly into the air vent

2. Press the upper part of the Proclip forward and lift the angled edge upwards, over the edge of the air vent. Press down on the upper part of the Proclip so that the angled edge hooks firmly into the air vent.

3. This bracket can also be placed on the left side of the center console.

4. The ProClip is in place.