

Manual, Assembly instruction: Brodit 655783

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the angled bottom of the ProClip into the gap between the glove compartment and the dashboard, right next to the hole for the hinge.
2. Pull the upper part of the ProClip upwards/forwards. Hook the angled upper part to the frame that surrounds the air vent.
3. Press down on the top of the ProClip so that the angled edge engages properly. Close the glove compartment.
4. The ProClip is in place.