

Manual, Assembly instruction: Brodit 655825

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.
2. Press the edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the ProClip upward and forward and hook the grooved lower edge over the frame surrounding the air vent.
4. The ProClip is in place.