

Manual, Assembly instruction: Brodit 655833

Angled mount Suitable for smaller tablet

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook/place the angled bottom of the ProClip into the gap between the glove compartment and the dashboard.

2. Pull out the rubber sealant a little to widen the gap.

3. Hook the angled upper part of the ProClip into the gap under the rubber sealant.

4. The ProClip is in place.