


## Manual, Assembly instruction: Brodit 655852

Center mount



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the bottom air vent and the surrounding frame. Press downward so the angled edge goes all the way into the gap.

2. Press the lower part of the ProClip downward. Then press the lower part of the ProClip forward and insert the angled lower edge into the gap between the air vent and the surrounding frame around the vent. Press upward so the angled edge goes all the way into the gap.

3. This ProClip can be placed anywhere within the width of the air vents.

4. The ProClip is in place.