

Manual, Assembly instruction: Brodit 655866

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached when the mount is in place.

1. Insert the lower lip in the seam between the digital cockpit and the plastic surround trim.
2. Use both hands to flex the upper lip to hook onto the plastic trim next to the driver's side vent.
3. The ProClip is in place.
4. The ProClip is in place.