

Manual, Assembly instruction: Brodit 655903

Center mount Only For 12" Screen.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Attach the mount parts together and secure with the included plate and screws. Screw the face plate onto the mount. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover on the mount.

2. Place the mount over the screen so the face plate is on the drivers side of the screen. Press the sides out slightly on the mount.

3. Press down on the mount until the angled part of the mount stops against the screen. Press the sides against the screen.

4. The ProClip mount is in place.