

Manual, Assembly instruction: Brodit 656008

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the left edge of the ProClip, with adhesive tape, over the frame surrounding the control panel.

2. Press forward on the right side of the ProClip, so the angled edge hooks into the gap on the center console.

3. The ProClip is in place.

4. The ProClip is in place.