

Manual, Assembly instruction: Brodit 656017

Angled mount


1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. Part 1. J shaped ProClip mount. Part 2 mounting plate.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner)s into the gap underneath the center console frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover.

2. Place part 1, the J-shaped ProClip bracket between the Gap Opener (Spaltöffner)s on the center console frame.

3. Screw part 2 onto the left side of the bracket so that the bracket sits properly and firmly in place.

4. The ProClip is in place.