

Manual, Assembly instruction: Brodit 656031

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the angled upper edge of the mount under the frame surrounding the air vent housing.

2. Press upward on the lower part of the mount.

3. Press forward on the lower part of the mount. Hook the angled lower edge over the frame surrounding the air vent housing.

4. The ProClip is in place.