

Manual, Assembly instruction: Brodit 656040

Center mount

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the angled edge on the upper part of the mount into the gap between the frame surrounding the air vent and the dashboard.

2. Press the lower part of the mount upward and forward. Hook the lower edge over the frame surrounding the air vent. Press forward on the lower part of the mount so the edge hooks + snaps properly in place.

3. This mount can be placed onto the left air vent provided that the installed device + equipment will not interfere with access or visibility.

4. The ProClip mount is in place.