

Manual, Assembly instruction: Brodit 656043

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Press the thin edge of the included gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape cover. Press the lower edge of the mount into the gap between the trim and the center console and hook the angled edge under the trim.

2. Pull the upper part of the mount upward and hook the angled edge into the gap next to the gap opener.

3. Press down on top of the mount so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip mount is in place.