

Manual, Assembly instruction: Brodit 656108

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the included gap openers into the gap in the center console sidewall, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

2. Hook the right edge of the mount over the frame surrounding the center console.

3. Press forward on the left side of the mount so the angled edge hooks into the gap between the gap openers. Press on the left edge so it goes all the way into the gap. Pull out the gap openers.

4. The ProClip mount is in place.