

Manual, Assembly instruction: Brodit 656115

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount under the dashboard overhang. Press the mount upward so the upper edge goes into the gap between the bright trim and the dashboard.

2. Press the lower part of the mount upward and forward.

3. Press the lower part of the mount forward so the edge hooks into place over the lower frame surrounding the air vent.

4. The ProClip mount is in place. The mount may be placed as desired within the width of the center air vents, provided the mounted device/equipment does not obstruct visibility and access.