

Manual, Assembly instruction: Brodit 802778

Left mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the upper part of the ProClip into the gap between the dashboard and the frame surrounding the air vent.
2. Press the lower part of the ProClip into the gap between the dashboard and the frame surrounding the air vent.
3. The ProClip is in place.
4. The ProClip is in place.