

Manual, Assembly instruction: Brodit 802916

Left mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent to widen the gap.
2. Press the lower part of the ProClip into the gap between the dashboard and the frame surrounding the air vent.
3. Press the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.