

## Manual, Assembly instruction: Brodit 802987

Left mount



**Attention! Read all instructions before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent to widen the gap.
2. Press the angled edge of the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the grooved edge of the lower part of the ProClip into the gap between the dashboard and the frame surrounding the air vent.
4. The ProClip is in place.