

Manual, Assembly instruction: Brodit 803041

Left mount



Attention! Read all instructions before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the upper part of the ProClip into the gap in the dashboard, by the windshield. Slide the ProClip to the left in the gap.
2. Press downwards on the upper part of the ProClip, in the same time pull the lower part of the ProClip downwards so the curved upper edge hooks into the gap.
3. Press the lower part of the ProClip into the gap between the wood grain panel and the frame surrounding the air vent.
4. The ProClip is in place.