

Manual, Assembly instruction: Brodit 803043

Left mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the lower part of the ProClip into the gap between the dashboard and the frame surrounding the air vent.
2. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent to widen the gap. Press it into the gap above the right side of the air vent.
3. Press the upper part of the ProClip into the gap next to the gap opener. If the gap is too tight, move the gap opener to the left side of the ProClip and press downwards alternately on the right/left side on the upper part of the ProClip. Pull out the gap opener.
4. The ProClip is in place.