

Manual, Assembly instruction: Brodit 803184

Left mount


1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Pull out the rubber. Hook the angled edge of the ProClip around the edge under the rubber.
2. Press forward on the ProClip so the other angled edge hooks behind the edge.
3. Press on the ProClip so it is properly in place.
4. The ProClip is in place.