

Manual, Assembly instruction: Brodit 803198

Left mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge on the upper part of the ProClip into the gap in the dashboard, to the right of the air vent.
2. Press forwards on the left part of the ProClip so the angled right part hooks into the gap.
3. Hook the angled edge on the left part of the ProClip into the gap between the dashboard and the air vent frame.
4. The ProClip is in place.