

Manual, Assembly instruction: Brodit 803268

Left mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the air vent frame and the dashboard to widen the gap. Place the gap openers about 10 cm apart. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the gap openers. Pull out the gap openers.

2. Press a gap opener into the gap between the air vent frame and the dashboard. Press forwards on the ProClip so the angled edge hooks into the gap next to the gap opener. Pull out the gap opener.

3. Press downwards on top of the ProClip so it goes all the way into the gap.

4. The ProClip is in place.