

Manual, Assembly instruction: Brodit 803278

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the left corner of the grooved upper part of the ProClip into the gap to the right of the gap opener. Pull out the gap opener.
2. Press the gap opener into the gap to the right of the ProClip. Press the right corner of the grooved upper part of the ProClip into the gap. Press forwards on the ProClip so it goes all the way into the gap. Pull out the gap opener.
3. Hook the lower part of the ProClip into the coin compartment under the frame surrounding the air vent.
4. The ProClip is in place.