

## Manual, Assembly instruction: Brodit 803291

Left mount NOT for models with storage compartment below the air vent.



**Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
2. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard.
3. Press forwards on the gap opener so the gap is widened. In the same time: press the grooved upper part of the ProClip into the gap next to the gap opener. Slide the ProClip to the right, as far as possible. Pull out the gap opener.
4. The ProClip is in place.