

Manual, Assembly instruction: Brodit 803362

Left mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the grooved edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the control panel. Press until you hear/feel it snaps into place.

2. Press the grooved edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the control panel. Press until you hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.