

Manual, Assembly instruction: Brodit 803409

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the control panel, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the angled edge in the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
4. The ProClip is in place.