

Manual, Assembly instruction: Brodit 803443

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the control panel, to widen the gap.

2. Press the angled edge of the lower part of the ProClip into the gap next to the gap opener. Flip the upper part of the ProClip upwards so the angled lower edge hooks behind the control panel. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Press forwards on the upper part of the ProClip so the grooved edge snaps into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.