

Manual, Assembly instruction: Brodit 803501

Left mount, Right

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the lower grooved edge on the ProClip into the gap between the frame surrounding the air vent and the dashboard. Press until you hear/feel it snaps into place.

2. Press the grooved edge on the ProClip into the gap between the frame surrounding the gap opener. Press until you hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.