

Manual, Assembly instruction: Brodit 803504

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the over of the adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the gap in the dashboard.

2. Press the ProClip upwards/forwards so the angled lower edge hooks into the gap.

3. Press forwards on the upper part of the ProClip so the grooved edge goes into the gap between the frame surrounding the instrument panel and the dashboard. Press until you hear/feel it snaps into place

4. The ProClip is in place.