

Manual, Assembly instruction: Brodit 803582

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Pull out the rubber covering and hook the angled left edge of the ProClip behind the edge.

2. Press forwards on the right side of the ProClip so the long right end hooks behind the edge by the window.

3. Press on the ProClip so it hooks into place properly.

4. The ProClip is in place.