

Manual, Assembly instruction: Brodit 803596

Left mount ONLY for models with factory navigation. NOT for wood grain panel. NOT for coupé.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the dashboard and the air vent panel frame/silver trim, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Slide the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Slide the gap opener, while in the gap, further towards the steering wheel to keep the gap widened and place it above the light switch. Slide the ProClip further into the gap so it is positioned next to the gap opener. Pull out the gap opener.

3. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap between the silver trim and the padded part of the dashboard. Press until you see or hear/feel it snaps into place.

4. The ProClip is in place.