

Manual, Assembly instruction: Brodit 803606

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Hook the lower part of the ProClip, with adhesive tape, under the edge of the dashboard surrounding the air vent.
3. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press downwards on top of the gap opener so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.