

Manual, Assembly instruction: Brodit 803612

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the curved edge on the right part of the ProClip into the gap below the gap openers.
3. Press the ProClip leftwards so the curved right edge hooks behind the frame surrounding the air vent. Press forwards on the left side of the ProClip so the angled left edge hooks into the gap in the dashboard sidewall. Pull out the gap opener.
4. The ProClip is in place.