

Manual, Assembly instruction: Brodit 803671

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Flip the upper part of the ProClip upwards so the curved lower edge hooks behind the frame surrounding the control panel. Pull out the gap opener. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard, in the same time press forwards on the upper part of the ProClip so the angled upper edge hooks into the gap next to the gap opener.

3. Pull out the gap opener. Press downwards on top of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.