

Manual, Assembly instruction: Brodit 803725

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap.

2. Hook/press the cruved edge on the upper part of the ProClip into the gap between the air vent frame and the dashboard. Flip the ProClip downwards so the curved upper edge hooks under the air vent frame.

3. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.