

Manual, Assembly instruction: Brodit 803875

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Grab a hold of the dashboard overhang and pull it upwards, in the same time hook the angled edge on the upper part of the ProClip behind the panel under the the dashboard overhang.
2. Slide the ProClip all the way to the left.
3. Pull the lower part of the ProClip towards you and hook the angled edge into the upper part of the air vent.
4. The ProClip is in place.