

Manual, Assembly instruction: Brodit 803906

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap in the upper part of the air vent housing.
2. Press the lower part of the ProClip upward and forward so the lower edge hooks into the lower part of the air vent.
3. Place your fingers inside the ProClip and press downward so the adhesive tape attaches.
4. The ProClip is in place.