

Manual, Assembly instruction: Brodit 803907

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber by the panel slightly.
2. Hook the angled edge on the lower part of the ProClip behind the panel, under the rubber.
3. Adjust the ProClip into desired position by sliding it upward/downward. Hook the angled edge on the upper part of the ProClip behind the panel so the ProClip snaps into place.
4. The ProClip is in place.