

## Manual, Assembly instruction: Brodit 803996

Left mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the air vent and the dashboard, to widen the gap above the air vent. Hook the angled edge on the upper part of the ProClip into the gap between the gap openers. Pull out the gap openers.
2. Press the gap openers into the gap between the frame surrounding the air vent and the dashboard, below the air vent. Press forward on the ProClip so the angled edge on the lower part goes into the gap between the gap openers.
3. Press forward on the ProClip so both edges go all the way into the gaps. Pull out the gap openers.
4. The ProClip is in place.