

Manual, Assembly instruction: Brodit 803997

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the climate control, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the grooved edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard. Press until you hear/feel it snaps into place.
3. Press the lower part of the ProClip upward/forward. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.