

Manual, Assembly instruction: Brodit 804006

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the panel frame surrounding the instruments, to widen it. Peel off the cover of adhesive tape on the ProClip.

2. Hold the ProClip in a vertical position. Press the curved edge on the right side of the ProClip into the gap above the gap opener. Flip the left side of the ProClip towards the air vent, so the curved edge on the right side hooks underneath the panel frame. Pull out the gap opener.

3. Press the gap opener into the gap between the dashboard and the air vent panel frame. Bend on the gap opener with your left hand and press firmly forward on the left side of the ProClip with your right hand, so the grooved edge goes into the gap above the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.