

Manual, Assembly instruction: Brodit 804060

Left mount, High NOT for Cabriolet.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Pull the rubber cover slightly out from the panel. Hook the angled edge of the ProClip around the panel under the rubber cover. Put the rubber back into place.
2. Press forward/upward on the ProClip so the angled edge hooks around the panel by the windshield.
3. Adjust the ProClip into desired position by sliding it upward/downward. Press the ProClip toward the panel so the angled edge goes all the way into the gap and the adhesive tape attaches.
4. The ProClip is in place.