

Manual, Assembly instruction: Brodit 804061

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

2. Bend the gap slightly wider by pressing the gap opener downward. In the same time, press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

3. Press forward on the upper part of the ProClip so the angled edge goes into the gap between the frame surrounding the air vent and the dashboard. Press downward on top of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.