

Manual, Assembly instruction: Brodit 804064

Left mount, High NOT for GTC model.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the ProClip over the panel by the windshield, but do not attach the adhesive tape yet.

2. Hold the enclosed gap opener upright on the dashboard and adjust the height of the ProClip so the lower edge is aligned with the gap opener, placed one gap opener length above the dashboard.

3. Pull the rubber cover slightly out from the panel. Hook the angled edge on the ProClip around the panel, under the rubber cover. Press on the ProClip so the adhesive tape attaches.

4. The ProClip is in place.