

Manual, Assembly instruction: Brodit 804073

Left mount NOT for 308 CC.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape cover on the ProClip. Pull out the rubber cover slightly. Hook the angled edge on the ProClip around the panel, under the rubber cover.
2. Press the ProClip forward/toward the panel so the angled edge hooks around the panel.
3. Slide the ProClip downward.
4. The ProClip is in place.