

Manual, Assembly instruction: Brodit 804107

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the front part of the ProClip around the upper air vent panel frame edge.

2. Place your thumb onto the upper part of the ProClip (behind the face plate). Push firmly forward on the ProClip so the angled edge on the back part of the ProClip snaps around the last part in the air vent.

3. The ProClip is in place.

4. The ProClip is in place.