

Manual, Assembly instruction: Brodit 804125

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Pull/flip the rubber sealant by the A-post open. Insert the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post panel edge and the rubber sealant.

2. Press firmly upwards with your left hand on the bottom part of the ProClip and leftward on the right side of the ProClip with your other hand. Press until you see or hear/feel the angled edge on the upper part of the ProClip snap around the A-post panel edge.

3. Press on the upper part of the ProClip so the angled edge hooks properly in place.

4. The ProClip is in place.