

Manual, Assembly instruction: Brodit 804134

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the thin end of the enclosed gap opener into the gap between the A-post and the rubber sealant so you can pull/flip the rubber sealant by the A-post open.

2. Insert the angled edge on the lower part of the ProClip under the rubber sealant and hook it behind the A-post panel edge. Press on the lower part of the ProClip so the lower angled edge hooks into place properly.

3. Press the upper part of the ProClip upward and leftward so the angled edge hooks around the A-post by the windshield. Press until you see or hear/feel the angled edge on the upper part of the ProClip snap around the A-post panel edge.

4. The ProClip is in place.