

## Manual, Assembly instruction: Brodit 804136

Left mount, High



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Peel off the cover of adhesive tape on the ProClip. Press the thin end of the enclosed gap opener into the gap between the A-post panel frame and the rubber sealant. Pull/flip the rubber sealant open. Pull out the gap opener.

**2.** Insert the angled edge on the lower part of the ProClip into the gap under the rubber sealant and hook it behind the A-post panel edge.

**3.** Press firmly upwards and leftward on the ProClip so the upper angled edge snaps around the A-post panel edge. Press down on top of the ProClip so the angled edge goes all the way into the gap.

**4.** The ProClip is in place.