

Manual, Assembly instruction: Brodit 804168

Left mount NOT for Cabriolet model.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the A-post and the panel frame. Peel off the adhesive tape covers on the ProClip.

2. Hook the angled edge on the upper part of the ProClip around the A-post by the windscreen.

3. Pull the ProClip toward you and hook the angled edge into the gap next to the gap opener. Press on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.